

C25 Rinse & Descale Tab

Professional detergent for Electrolux Professional SkyLine Ovens

Electrolux C25 rinse aid and descaling tabs, 2 in 1 solution, combine rinsing and limestone removal. Especially developed for Electrolux skyline professional ovens, featuring the Electrolux Cleaning System. Regular use of C25 tabs guarantee the removal of limestone in the oven cavity and in the boiler ensuring product performance whilst also maintaining relevant warranty conditions.



Images shown are a representation of the product only and variations may occur.

Applications

For Electrolux Professional ovens featuring the Electrolux Cleaning System.

Description

C25 rinse & descale tabs are high effective combining rinsing and limestone removal, in a 2-in-1 solution.

Guarantees hygiene safety for healthy food preparation.

- ▶ Simple application in an easy to use dosage.
- ▶ Minimal environment impact achieved through degradable ingredients
- ▶ Alkaline level, pH (1%) $\geq 2,3$
- ▶ Works in combination with Electrolux C22 & C23 Cleaning agents.
- ▶ Semi-transparent container packaging provides easy re-order indication

Product developed and tested by Electrolux.

C25 rinse & descale tabs work in harmony with Electrolux Professional SkyLine ovens featuring the Electrolux Cleaning System. Best rinsing & descaling performance is achieved when the C25 tab is used in conjunction with the oven cleaning programme, in accordance with Electrolux user specifications.

Chemical-physical characteristics

Appearance	round tablet / diameter 35 mm in foil wrapping
Colour	white, slightly yellow
Odour	characteristic, acidic
Weight	30 g
Solubility	completely soluble in water
pH (1%)	$\geq 2,3$



Instruction for use

1. Wear protective gloves and safety glasses when handling the product
2. Insert the C25 Rinse & Descale Tab in the appropriate drawer of the Rinse & Descale tab container of the oven
3. Enter the washing cycle program and follow the on-screen instructions

Packs:

Bucket container with 50 tabs.

Code: 0S2394

Warnings:

- ▶ Intended for professional use only; do not use in household appliances
- ▶ Store in a cool and dry place
- ▶ Keep the bucket closed
- ▶ To be used within 36 month from the date of production
- ▶ Used sachets and container bucket can be recycled in accordance to current legislation and local conditions
- ▶ For further information please refer to product labelling and the safety data sheet

