

C23 Cleaning Powder

Professional detergent for Electrolux Professional SkyLine Ovens

Electrolux C23 Cleaning Powder has been especially developed for Electrolux skyline professional ovens, featuring the Electrolux Cleaning System. Regular use of C23 powder guarantees hygienic cleanliness of your equipment, ensuring product performance whilst also maintaining relevant warranty conditions.

Applications

For Electrolux Professional ovens featuring the Electrolux Cleaning System.

Description

C23 cleaning powder is a phosphate free, environmentally friendly, high effective detergent for thorough and hygienic cleaning of greasy, oily and burnt-in soils.

- ▶ Guarantees hygiene safety for healthy food preparation
- ▶ Simple application in an easy to use dosage.
- ▶ Minimal environment impact achieved through degradable ingredients
- ▶ Alkaline level, pH (1%) > 13
- ▶ Works in combination with Electrolux C25 Rinse and Descale agent.
- ▶ Semi-transparent container packaging provides easy re-order indication

Product developed and tested by Electrolux.

C23 cleaning agents works in harmony with Electrolux Professional SkyLine ovens featuring the Electrolux Cleaning System. Best cleaning performance is achieved when the C23 cleaning agent is used in conjunction with the oven cleaning programme, in accordance with Electrolux user specifications.

Chemical-physical characteristics

Appearance	powder in foil wrapping sachet
Colour	white / yellowish
Odour	characteristic
Weight	65 g
Solubility	completely soluble in water
pH (1%)	> 13



Images shown are a representation of the product only and variations may occur.



Instruction for use

1. Wear protective gloves and safety glasses when handling the product
2. Pour the C23 Cleaning Powder into the dedicated basket of the integrated cleaning system on the bottom of the oven cavity
3. Enter the washing cycle program and follow the on-screen instructions

Packs:

Bucket container with 100 powder sachets.

Code: 0S2392

Warnings:

- ▶ Intended for professional use only; do not use in household appliances
- ▶ Store in a cool and dry place
- ▶ Keep the bucket closed
- ▶ To be used within 36 month from the date of production
- ▶ Used sachets and container bucket can be recycled in accordance to current legislation and local conditions
- ▶ For further information please refer to product labelling and the safety data sheet

